



# Assembly Instructions for Fan Programs

You will need a strip of double-sided tape, a wooden handle and one of each printed program sides for each Fan Program.




**1**




Cut the double-sided tape in half. Use the 2" strip for the handle. Cut the remaining piece of tape into four 1/2" pieces. Remove one side of the backing from each piece of tape.

**2**



Place the four smaller pieces of tape on the backside of one sheet of the program in each corner as shown. Place the longer piece of tape on one side of wooden handle. Remove the backing from the tape on the handle. Place the wooden handle on the back of the program and press firmly to adhere.

**3**



Remove the backing from the tape to expose the other sticky side. Position the other side of the program, copy side up, on top of the program and handle. Once the two programs are positioned together, press firmly in all areas where tape is located to ensure proper adhesion.

